


## Setting up the T38 Jaw and Jaw Scheme in TestWise

This process has two (2) steps:

1. Setup the Jaw
2. Setup Jaw Scheme

### Jaw

In TestWise, goto File > Options > Jaws



Click the New button

Type the Name "T38"

Enter the Offset "11" mm


Check the two (2) boxes

Click Apply

The T38 Jaw is now setup.

See next page to setup the Jaw Scheme.

## Jaw Scheme



Click on Jaw Schemes, then New



Type the Name and Description as shown here

Select the Top and Bottom jaws

Tension mode is selected as default

Then click Jog Mode


Continued over page.



Move to top T38 grip to within 50 to 100 mm of the bottom grip.  
Measure the exact distance, in this illustration, it is 80 mm.

Enter the measured distance as shown above and then click Save Reference Position.


Continued over page.



The Reference Position will be calculated and populate automatically. This value is an example only.

Click Apply then click OK to save the newly created Jaw Scheme.

The Jaw Scheme can now be used.



<http://appsupport.james-heal.co.uk/support/home>