

## Changing the Sound Settings on the Martindale 900 Series

**WARNING:** Any maintenance work undertaken on a James Heal instrument must be done so by a trained and competent person. Where electrical work is detailed, this should only be completed by a qualified engineer. James Heal is not responsible for damage or injury arising from work carried out by any person not qualified to do so. If in doubt, please contact James Heal or your local James Heal Agent.

### *In English:*

On the pre-set count keypad;

Press  the display will show Mode

Press and continue pressing  the display will first show Sound

then after 1 second it will change to show Edit now stop pressing 

The display will then show the current sound setting, either;

0 = Off or 1 = Beep or 2 = Voice

To turn the sound off press , or to change the sound to a beep press 

or to change the sound to a voice press 

After selecting the desired option press 

If either “Beep” or “Voice” have been selected the display will now show Volume

then show Edit then show the current volume setting Vol 5

Select the desired volume level (From 1 to 6) by pressing a number 1 to 6.

After selecting the desired volume press  to return to normal operation.

***With the language set to German:***

On the pre-set count keypad;

Press  the display will show Modus

Press and continue pressing  the display will first show Klang

then after 1 second it will change to show Anderung now stop pressing 

The display will then show the current sound setting, either;

0 = Off or 1 = Beep or 2 = Voice

To turn the sound off press , or to change the sound to a beep press 

or to change the sound to a voice press 

After selecting the desired option press 

If either “Beep” or “Voice” have been selected the display will now show Volume

then show Anderung then show the current volume setting Vol 5

Select the desired volume level (1 to 6) by pressing a number 1 to 6.

After selecting the desired volume press  to return to normal operation.